







## Pump Vault 15000/55000 Increase 55000

|    |                             |
|----|-----------------------------|
| DE | Gebrauchsanleitung          |
| EN | Operating instructions      |
| FR | Notice d'emploi             |
| NL | Gebruiksaanwijzing          |
| ES | Instrucciones de uso        |
| PT | Instruções de uso           |
| IT | Istruzioni d'uso            |
| DA | Brugsanvisning              |
| NO | Bruksanvisning              |
| SV | Bruksanvisning              |
| FI | Käyttöohje                  |
| HU | Használati útmutató         |
| PL | Instrukcja użytkowania      |
| CS | Návod k použití             |
| SK | Návod na použitie           |
| SL | Navodila za uporabo         |
| HR | Uputa o upotrebi            |
| RO | Instrucțiuni de folosință   |
| BG | Упътване за употреба        |
| UK | Посібник з експлуатації     |
| RU | Руководство по эксплуатации |
| CN | 使用说明书                       |







|   |   |   |                                    |
|---|---|---|------------------------------------|
|  | <p><b>Pump Vault 15000</b><br/>Aquarius Universal Premium 12000</p> | <p><b>Pump Vault 55000</b><br/>Aquarius Universal Premium 20000<br/>Aquarius Eco Expert 28000</p> | <p><b>Increase 55000</b><br/>—</p> |
|---|---|---|------------------------------------|




### Pump Vault 15000



### Pump Vault 55000



### Increase 55000




PVT0003



### Pump Vault 15000


Ø max. 38 mm




Water Replenishment System

### Pump Vault 55000




4x 



### Increase 55000



PVT0004



PVT0007

